













	<b>UTA 115</b> Universal-Untertasse 14 cm D 14,0 x H 2,0 x M 4,8 cm, flache Form	VE 48/6		<b>UTA 214</b> Universal-Untertasse 14 cm (**) D 14,0 cm, flache Form	VE 48/6
	<b>UTA 115 S</b> Universal-Untertasse 14 cm schwarz D 14,5 x H 2,0 x M 4,8 cm, flache Form	VE 48/6		<b>UTA 117</b> Universal-Untertasse 16 cm D 16,0 x H 2,2 x M 5,2 cm, flache Form, kleiner Spiegel	VE 24/6
	<b>YK 1131</b> Universal-Untertasse 13 x 13 cm L 13,0 x B 13,0 x H 2,0 x M 4,9 cm, Form YoYo	VE 48/6		<b>UTT 170</b> Universal-Untertasse 17 cm (**) D 16,5 x H 2,5 x M 5,2 cm, Form Stabrand	VE 48/6
	<b>UTT 145</b> Universal-Untertasse 14 cm (**) D 14,5 x H 2,0 x M 5,2 cm, Form Stabrand	VE 48/6		<b>TT 016</b> Universal-Untertasse 16 x 13 cm L 16,0 x B 13,5 x H 1,5 x M 5,2 cm	VE 48/6
	<b>CF 018</b> Universal-Untertasse 18 x 14 cm (**) L 18,0 x B 14,0 x H 2,5 x M 5,1 cm, spitze Form	VE 48/6		<b>UTS 145</b> Universal-Untertasse 14 cm 1 Spiegel D 14,5 x H 2,0 x M 5,3 cm, 1 Spiegel	VE 72/6
	<b>FD 016</b> Universal-Untertasse 16 x 16 cm L 16,0 x B 16,0 x Q 19,0 x M 5,1 x H 2,0 cm	VE 48/6		<b>UTS 140</b> Universal-Untertasse 14 cm 2 Spiegel D 14,0 x H 2,3 x M 7,0/5,3 cm Doppelspiegel	VE 72/6
	<b>UTM 015</b> Universal-Untertasse 15 cm D 15,0 x H 2,0 x M 5,1 cm, asymmetrische Form	VE 48/6		<b>GVP 058</b> Setplatte klassisch 24 x 10 cm, 2 Spiegel (**) L 23,6 x B 9,6 x H 2,5 cm x M 6,8/5,3 cm Doppelspiegel	VE 48/6
	<b>UTA 114</b> Universal-Untertasse 14 cm D 14,0 x H 2,0 x M 5,2 cm, flache Form	VE 48/6			

